

# FERROXCUBE - your global partner

**Australia:** Contact Ferroxcube Taiwan  
Tel: +886 2 86650099, Fax: +886 2 86650145

**Austria:** Contact Ferroxcube Germany  
Tel: +49 (040) 527 28 305, Fax: +49 (040) 527 28 306

**Benelux:** Ferroxcube Netherlands, EINDHOVEN  
Tel: +31 (0)40 27 24 216, Fax: +31 (0)40 27 24 411

**Canada:** Contact Ferroxcube USA  
Tel: +1 915 599 2513/2328, Fax: +1 915 599 2555

**China:** Ferroxcube Hong Kong, SHANGHAI  
Tel: +86 21 6380 0607 / 3121, Fax: +86 21 6380 0910

**Czech Republic:** Contact Ferroxcube Poland  
Tel: +48 46 834 00 07, Fax: +48 46 834 00 35

**Denmark:** Contact Ferroxcube Sweden  
Tel: +46 8 580 119 76, Fax: +46 8 580 121 60

**Finland:** Contact Ferroxcube Sweden  
Tel: +46 8 580 119 76, Fax: +46 8 580 121 60

**France:** Ferroxcube France, NANTERRE  
Tel: +33 (01) 5551 8422, Fax: +33 (01) 5551 8423

**Germany:** Ferroxcube Germany, HAMBURG  
Tel: +49 (040) 527 28 302, Fax: +49 (040) 527 28 306

**Greece:** Contact Ferroxcube Italy  
Tel: +39 02 241131 1, Fax: +39 02 241131 11

**Hungary:** Contact Ferroxcube Poland  
Tel: +48 46 834 00 07, Fax: +48 46 834 00 35

**Hong Kong:** Ferroxcube Hong Kong, HONG KONG  
Tel: +852 2319 2740, Fax: +852 2319 2757

**Indonesia:** Contact Ferroxcube Singapore  
Tel: +65 6244 7815, Fax: +65 6449 0446

**Ireland:** Contact Ferroxcube UK  
Tel: +44 1306 646200, Fax: +44 1306 646222

**Israel:** Arrow\Rapac Ltd., PETACH TIKVA  
Tel: +972 3 9203480, Fax: +972 3 9203443

**Italy:** Ferroxcube Italy, SESTO S. GIOVANNI (MI)  
Tel: +39 02 241131 1, Fax: +39 02 241131 11

**Malaysia:** Contact Ferroxcube Singapore  
Tel: +65 6244 7815, Fax: +65 6449 0446

**Mexico:** Contact Ferroxcube USA  
Tel: +1 915 599 2513/2328, Fax: +1 915 599 2555

**New Zealand:** Contact Ferroxcube Taiwan  
Tel: +886 2 86650099, Fax: +886 2 86650145

**Norway:** Contact Ferroxcube Sweden  
Tel: +46 8 580 119 76, Fax: +46 8 580 121 60

**Philippines:** Contact Ferroxcube Singapore  
Tel: +65 6244 7815, Fax: +65 6449 0446

**Poland:** Ferroxcube Polska, SKIERNIEWICE  
Tel: +48 46 834 00 07, Fax: +48 46 834 00 35

**Portugal:** Contact Hispano Ferritas, Spain  
Tel: +34 (93) 317 2518, Fax: +34 (93) 302 3387

**Singapore:** Ferroxcube Singapore, SINGAPORE  
Tel: +65 6244 7815, Fax: +65 6449 0446

**Slovak Republic:** Contact Ferroxcube Poland  
Tel: +48 46 834 00 07, Fax: +48 46 834 00 35

**Spain:** Hispano Ferritas, BARCELONA  
Tel: +34 (93) 317 2518, Fax: +34 (93) 302 3387

**Sweden:** Ferroxcube Sweden, JÄRFÄLLA  
Tel: +46 8 580 119 76, Fax: +46 8 580 121 60

**Switzerland:** Contact Ferroxcube Germany  
Tel: +49 (040) 527 28 305, Fax: +49 (040) 527 28 306

**Taiwan:** Ferroxcube Taiwan, TAIPEI  
Tel: +886 2 86650099, Fax: +886 2 86650145

**Turkey:** Contact Ferroxcube Italy  
Tel: +39 02 241131 1, Fax: +39 02 241131 11

**United Kingdom:** Ferroxcube UK, DORKING  
Tel: +44 1306 646200, Fax: +44 1306 646222

**United States:** Ferroxcube USA, EL PASO (TX)  
Tel: +1 915 599 2513/2328, Fax: +1 915 599 2555

**For all other countries apply to closest regional sales office:**

■ HAMBURG, Germany  
Tel: +49 (040) 527 28 302, Fax: +49 (040) 527 28 306  
e-mail: sales europe@ferroxcube.com

■ EL PASO (TX), USA  
Tel: +1 915 599 2513/2328, Fax: +1 915 599 2555  
e-mail: sales usa@ferroxcube.com

■ TAIPEI, Taiwan  
Tel: +886 2 86650099, Fax: +886 2 86650145  
e-mail: sales asia@ferroxcube.com

© Ferroxcube International Holding B.V. 2003

All rights are reserved. Reproduction in whole or in part is prohibited without the prior written consent of the copyright owner.  
The information presented in this document does not form part of any quotation or contract, is believed to be accurate and reliable and may be changed without notice. No liability will be accepted by the publisher for any consequence of its use. Publication thereof does not convey nor imply any license under patent- or other industrial or intellectual property rights.

Visit our web-site for the latest information on new products, application info as well as updated phone- and fax numbers

**Internet:** www.ferroxcube.com

Printed in The Netherlands 9398 288 01111 Date of release: January 2003

# Power Ferrite Measuring Setup EMMA 2.1





## Introduction

Formerly a Philips Components company FERROXCUBE now belongs to Yageo Corporation, one of the world's strongest suppliers of passive components.

As a leading innovator in ferrite-ceramic technology, we build on our Philips magnetic components heritage to offer a broad range of soft ferrite cores. We also offer extensive design-in support including application information and software to help equipment manufacturers optimize their new designs.

Our research and development laboratories located in Eindhoven, The Netherlands, can build on 50 years' experience in ferrite technology. This means we know everything about ferrite cores but also about what's needed to make and test them. The specifications and tolerances required for the industrial equipment are generally very demanding and critical. We bring along with us the experience gained by building our own measuring setups since the early years of the ferrite industry.

We offer a complete power ferrite measuring setup as it is used in all Ferroxcube facilities. This will contribute to a standardization of measurement methods throughout the ferrite industry.

The EMMA 2.1 is a computer controlled test unit fully equipped to characterise all important magnetic properties of soft ferrite cores in a wide temperature range. It is a vital tool in research and development as well as for sample testing in production.



The following magnetic properties of power ferrite cores can be measured with the "Standard Application Package":








- Power loss density ( $P_V$ )
- Peak flux density ( $B_p$ )
- Amplitude permeability ( $\mu_a$ )
- Curve of B-H-loop

To measure power losses the Digitizing Oscilloscope Method is used. Voltage on and current through the DUT are sampled in a few cycles of the BH-loop to avoid self-heating of the ferrite.

With the "Supplement Application Package" the system has the following measuring capabilities:

- Initial permeability ( $\mu_i$ )
- Temperature factor ( $\alpha_F$ )
- Disaccommodation factor ( $D_F$ )
- Inductance factor ( $A_L$ )
- Temperature curve of permeability
- Loss factor ( $\tan\delta/\mu_i$ )
- Hysteresis material constant ( $\eta_B$ )
- Resistivity ( $\rho$ )
- Curie temperature ( $T_C$ )

Contact us to find out more!



## Description of setup

The EMMA 2.1 is built in a Rittal cabinet with:

- LCR-meter 0 - 1 MHz
- Function generator 20 kHz - 10 MHz
- Digital Processing Oscilloscope (DPO)
- LF and HF amplifier frequency range: DC - 3 MHz voltage: 0 - 100 V peak current: 6 A peak (depending on load and frequency)
- Temperature chamber with 16-fold 4-pole relay matrix temperature range: -40 to 180 °C.
- Sample temperature chamber temperature range: up to 300 °C
- Industrial PC with I/O boards, modem and LAN.

The system will be delivered with:

- Flat LCD monitor and printer
- Windows 2000 and application software
- Remote diagnostics
- Set of certified test and calibration cores.
- Drawing package and documentation.

## Measuring range and accuracy General technical data

Power loss: 10 kHz - 3 MHz  
Voltage (B):  $\pm 1\%$   
Current (H):  $\pm 1\%$   
Temperature around 100 °C:  $\pm 1\%$

The accuracy of the loss measurement depends on the DPO, the inductance value of the DUT and the applied voltage (see graph).

Connected power:

Cabinet:  
110/230 V, 50/60 Hz, 1.0 kW

Temperature chamber:  
110/230 V, 50/60 Hz, 2.4 kW

Environment temperature:  
15 - 25 °C (climate control needed)

